

Technische Information

To all Export Sales Representatives
And Repair Workshops

Dear Ladies and Gentlemen,

Due to changes in Safety Regulations it is no longer allowed to use on certain models,
an ON/OFF Rocker switch
The Rocker switch must be replaced with a switch that has a lock against accidental starting
of the machine.
Therefore the tube type rear handle must be discontinued
This change affects all of the below listed models produced as of September 2009

Steinheim, 30.08.2009

Wolfgang Kreuzer

Conversion Rear handle assembly --- Lock out switch.

<u>Machine</u>	<u>Designation</u>	<u>Rear Handle Assembly</u>
		New
LK 602 VR 258580	230/CEE	207.233
349593		
LW 802 VR 258597	230/CEE	252.044
260282	110/CEE	250.956
LW 1202 276375	230/CEE	355.984
278424	110/CEE	355.992
LW 1202 S 289000	230/CEE	356.018
278483	120/USA	235.644
L 1202 278688	230/CEE	352.268
LK 604 250346	230/CEE	352.977

The following Rear handle assembly's
have been discontinued :

254602 LK 602 VR	230/CEE	
254621 LW 802 VR	230/CEE	
256257 LW 802 VR	110/CEE	
209880 LW 1202	230/CEE	
294713 LW 1202	110/CEE	
289078 LW 1202 S	230/CEE	
235644 LW 1202 S	120/USA	No Change